Pairing Method with QY Bluetooth Display QY Bluetooth Adapter User Manual

Short Press: Press the button once to power on the adapter. The indicator light will illuminate for 1 second. After powering on, the adapter enters a waiting for

Adapter Name Format: A_xxxx or Adapter-xxxx

- 1. If the adapter is not connected within 1 minute after powering on, it will automatically shut down.
- 2. If the adapter cannot be found during a search, long press the button for 5 seconds to reset the adapter's Bluetooth. Upon successful reset, the indicator light will illuminate solidly for 5 seconds.

Indicator Light Description:



Method One: Wireless Pairing

1. On the QY Bluetooth Display, long press the Bluetooth button for 3 seconds. The second digit will display a "fast blinking underscore", indicating entry into Bluetooth pairing mode.



The second digit of the digital Bluetooth button for 3 seconds tube will display a "fast blinking underscore"

2. Ensure the adapter you want to pair is powered on and is not currently bound or previously bound to another user.

①Power On: Short press the adapter button.



QY BLUETOOTH DISPLAY SCREEN STATUS INDICATORS Digital Tube Position 2 Digital Tube Positions 3-6

3. Wait for the Display to search for Bluetooth devices. The status indicators on

9 99 999 Blank: Indicates a Bluetooth Timer Fast Blinking: Searching for devices was found Last 4 digits of the found device's MAC address A: Indicates a Transmitter was found | Slow Blinking : Pairing with this device

4. If multiple devices nearby are in a pairable state, short press the Bluetooth button to cycle through and select the device you wish to pair with



5. Confirm the target device by observing its MAC address last 4 digits. Long press the Bluetooth button for 3 seconds to start pairing with that device. During pairing: The second digit will display a "slow blinking underscore".



the digital tubes are as follows:





QYTOYS

"slow blinking underscore"

The second digit of the digital tube will display a

*If pairing does not complete, ensure the adapter/second-generation timer is powered on.



6. Wait for pairing with the device to complete (usually 5-10 seconds). Upon

Method Two: Insert Bluetooth Adapter Pairing

Insert the Bluetooth adapter into the Display.

.....

@Yrors /

*Ensure the adapter has

batteries installed and is

successful pairing, the screen will display 0.000.

seconds to enter pairing mode.

2. Long press the Bluetooth button for 3



Long press the Bluetooth button for 3 seconds

powered on first. 3. Wait for the Display and adapter to pair automatically. Upon successful pairing,

the screen will display 0.000.

Pairing Method with App . Ensure the adapter you want to pair is powered on and is not currently bound

or previously bound to another user. *If it cannot be found, long press its button for 5 seconds to reset Bluetooth.



1. If the adapter is not connected within 1 minute after powering on, it will automatically 2. In the Smart Player Pro app, click on the "Hardware Timer" module. Then click the "Click here to connect timer" button at the bottom of the screen, followed 2. If the adapter cannot be found during a search, long press its button for 5 seconds to reset by the "Search for Devices" button





Adapter-xxxx.

Bluetooth. Upon successful reset, the indicator light will illuminate solidly for 5 seconds. 3. App Requirement: Use Smart Player Pro version 2.3.7 or later.

4. When not in use, do not leave the Bluetooth adapter plugged into the Display or Timer.



App Store

©For iPhone users, you can search for "Smart Player Pro" ip the APP Store to download and install the APP. For Andro"

3. Wait for the app to search for adapter. The adapter name format is:

4. Click the "Connect and Bind" or "Connect" button.

Battery Specification:

Use 2 x LR44 batteries.

Positive "+"